

## Bedienungsanleitung audio recorder Fostex UR-2

1. SD-Karte in **Slot SD-2** einstecken, Gerät einschalten (Power)

HINWEIS: Die SD-Karte darf nicht größer als 32 GB und muss FAT32 formatiert sein. Von der Verwendung von USB Sticks ist abzuraten

Die **LED** am SD-Slot leuchtet **grün**, wenn das Medium bereit ist (ggf. Schreibschutz überprüfen)

2. Taste **REC-RDY** drücken
3. Aufnahmestart: **REC** drücken (Counter läuft) – Aufnahmeformat ist: PCM 48 kHz, 24 bit
4. Zum Beenden/Pausieren der Aufnahme die Taste **STOP** drücken
5. Zum Abschluss: REC-RDY aus. Dann Gerät **ausschalten** und Karte entnehmen.

Viel Erfolg!

Sebastian Bonney – Tonmeister@Tonstudio HMT Leipzig  
Hotline: +49 151 624 20 644 (nicht 24/7)



## Operating Instructions audio recorder Fostex UR-2

1. Insert the SD card into **slot SD-2**, switch on the unit (Power)

NOTE: The SD card must not be larger than 32 GB and must be FAT32 formatted. The use of USB sticks is not recommended.

The green **LED** on the SD slot lights up **green** when the medium is ready (check write protection if necessary)

2. Press the **REC-RDY** key
3. Press **REC** to start recording (counter is running) – record format is: PCM 48 kHz, 24 bit
4. To stop/pause the recording, press the **STOP** key
5. To finish: REC-RDY off. Then switch off the unit and remove the card.

Good luck!

Sebastian Bonney - Tonmeister@Tonstudio HMT Leipzig  
Hotline: +49 151 624 20 644 (not 24/7)